

Copy the DO NOT UNPLUG graphic on bright colored paper

Laminate or place in a plastic sheet protector

Post on the front the refrigerator

Post near the wall plug the refrigerator is plugged into

Post near the power strip, if the refrigerator is plugged into one

